


RR-8116 AIR NIBBLER



Index No.	Part No.	Description	Q'ty
1	607B001	Housing Cover	1
2	607B002	Air Inlet Bushing	1
3	607B003	Exhaust Sleeve	1
4	607B004	O-Ring	1
5	607B005	Spring Pin	1
6	607B006	Spring Pin	1
7	607B007	Throttle Lever	1
8	607B008	Motor Housing	1
9	607B009	Valve Shaft	1
10	607B010	O-Ring	1
11	607B011	Throttle Valve	1
12	607B012	Valve Spring	1
13	607B013	O-Ring	1
14	607B014	Valve Screw	1
15	607B015	Ball Bearing	1
16	607B016	Rear End Plate	1
17	607B017	Spring Pin	1
18	607B018	Cylinder	1
19	607B019	Rotor	1
20	607B020	Rotor Blade	4
21	607B021	Spacer	1
22	607B022	Spring Pin	2
23	607B023	Front End Plate	1

Index No.	Part No.	Description	Q'ty
24	607B024	Ball Bearing	1
25	607B025	Internal Gear	1
26	607B026	Idler Gear	3
27	607B027	Idler Gear Pin	1
28	607B028	Idler Spindle	1
29	607B029	Nut	1
30	607B030	Snap Ring	1
31	607B031	Ball Bearing	2
32	607B032	Washer	1
33	607B033	Shaft	1
34	607B034	Drive Bushing	1
35	607B035	Plug	1
36	607B036	Pushing Rod Bushing	1
37	607B037	Nibbler Head	1
38	607B038	Pushing Rod Bushing	1
39	607B039	Pin	1
40	607B040	Pushing Rod	1
41	607B041	Cutter	1
42	607B042	Screw	1
43	607B043	Dies	1
44	607B044	Nut	1
45	607B045	Washer	1